



BAUHAUS™

saxophones have “Ribbed Construction” - this means the pillars are mounted on plates (or ribs) and attached to the body. This helps to strengthen key work and stabilise the saxophone body.

The Soprano, Tenor and Alto have fine adjustment screws, which help when setting up the instrument and mean that corks and felts don't have to be shaved or changed. The soprano has Bb/G# regulation screws, and the baritone has adjustable key guard felts for venting and tuning.

Blue Steel Needle Springs provide high tensile strength and consistent key action and fine grain Italian Leather pads with domed metal resonators give a positive, consistent action and longevity.

The crooks vary according to instrument - the soprano has an integral crook, while the sopranos come with two - one curved and one straight - for different playing positions. The alto has an Underslung crook, the tenor over-slung, and the baritone's three vent octave mechanism is on the body.

Hand-Hammered Bells.

HAND MADE

**Construction Throughout
Is Largely By Hand**

BAUHAUS™

